

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922) 49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольяти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://chaosensor.nt-rt.ru> || crx@nt-rt.ru

Многопараметрический потолочный интеллектуальный датчик воздуха



Products Description

The Ceiling-mounted Multiparameter Sensor is a product independently researched and developed by our company. It uses imported data acquisition chips, advanced production technology and surface mount technology, and the measurement data is accurate and reliable. It has been accurately calibrated during production, and the calibration data is stored in the internal memory. It is outstanding in measurement accuracy, linearity, repeat-ability, interchangeability, and consistency. In addition, the sensor has the characteristics of digital output and can be fully interchanged. It is suitable for environmental equipment matching, instrument equipment integration, and general environmental testing.

APPLICATION




Widely used in Biomedicine, Food Safety, Environmental Protection Supervision, Agricultural Greenhouses, Industrial Production, Animal Husbandry, Buildings, Meteorological Environmental Protection, Gardening Flowers, Home Life and other fields that require monitoring of environmental and meteorological.

Specification


Technical Parameters	Measuring Range	Resolution	Accuracy
Temperature	- 30 ~ 70°C	0.1°C	±0.2°C
Humidity	0 ~ 100%RH	0.1%RH	±3%RH
Illumination	0 ~ 200K Lux	10 Lux	±5%
Dew Point Temperature	- 100 ~ 40°C	0.1°C	±0.3°C
Aire Pressure	600 ~ 1100hPa	0.1hPa	±0.5hPa
CO2	0 ~ 5000ppm	1ppm	±75ppm + 2%Reading
Civil CO	0 ~ 500ppm	0.1ppm	±2%FS
PM1.0/2.5/10	0 ~ 1000µg/m3	1µg/m3	±3%FS
TVOC	0 ~ 5000ppb	1ppb	±3%
CH2O	0 ~ 5000ppb	10ppb	±3%
O2	0 ~ 25%VOL	0.1%VOL	±2%FS
O3	0 ~ 10ppm	0.01ppm	±2%FS
Air Quality	0 ~ 10mg/m3	0.05 mg/m3	±2%FS
NH3	0 ~ 100ppm	1ppm	±2%FS
H2S	0 ~ 100ppm	1ppm	±2%FS
NO2	0 ~ 20ppm	0.1ppm	±2%FS
Foul Smell	0 ~ 50ppm	0.01ppm	±2%FS
SO2	0 ~ 20ppm	0.1ppm	±2%FS
Cl2	0 ~ 10ppm	0.1ppm	±2%FS
Civil Gas	0 ~ 5000ppm	50ppm	±3%LEL

PRODUCT DISPLAY




Installation Method

First, punch holes in the wall, fasten the mounting base to the wall or ceiling, and snap the device buckle into the mounting base.



Schematic Diagram of Installing the Tray



Back Diagram of Installation

INTERFACE INTRODUCTION

- 1.Power Supply Voltage 7-24V DC (Output customization available)
- 2.POE Splitter Output Signal
Network port, support POE power supply.



Communication
Indicator Light

Communication
Interface

Power
Indicator Light

Power
Interface(DC)




Power Supply(DC)
Network Cable
Communication Transmission




POE Splitter
Ethernet Interface
Support POE Power Supply


WIRING DIAGRAM



INSTALLATION METHOD



Ceiling-mounted Installation



Wall-mounted Installation

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922) 49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
 Иваново (4932)77-34-06
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Саранск (8342)22-96-24
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сыктывкар (8212)25-95-17
 Сургут (3462)77-98-35
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Улан-Удэ (3012)59-97-51
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31